

CALIBRATING PROBE THERMOMETER

NOTE: Handle thermometer gently. Rough handling or dropping will cause it to lose calibration.

WHEN: Calibrate each thermometer frequently.

HOW:

1. Fill a medium sized glass with ice.
 - Add water to ice.
 - Place thermometer in glass of ice water.
2. Wait 3 minutes.
 - Stir water occasionally.
3. After 3 minutes, thermometer should read 32°F.

CORRECTIVE ACTION:

IF THERMOMETER DOES NOT READ 32°F:

1. Leave it in the ice water.
2. Using pliers or an adjustable wrench, turn adjustable nut on back of thermometer until needle reads 32°F.
 - It may be necessary to add more ice.
3. Wait 3 minutes, stir occasionally.
4. After 3 minutes, thermometer should read 32°F.
 - If not, repeat corrective action.